


## Typical two reader Weigand/Wiegand configuration



V7 PCBs:  
 Reader 1.....no5 ON  
 Reader 2.....no6 ON

V8 PCBs:  
 Reader 1.....no1 ON  
 Reader 2.....no2 ON

da/v8acu/1104